



**File Name:** campbell hausfeld pressure washer user manual.pdf

**Size:** 3354 KB

**Type:** PDF, ePub, eBook

**Category:** Book

**Uploaded:** 7 May 2019, 15:53 PM

**Rating:** 4.6/5 from 784 votes.

**Status:** AVAILABLE

Last checked: 19 Minutes ago!

**In order to read or download campbell hausfeld pressure washer user manual ebook, you need to create a FREE account.**

**[Download Now!](#)**

eBook includes PDF, ePub and Kindle version

[Register a free 1 month Trial Account.](#)

[Download as many books as you like \(Personal use\)](#)

[Cancel the membership at any time if not satisfied.](#)

[Join Over 80000 Happy Readers](#)

### **Book Descriptions:**

We have made it easy for you to find a PDF Ebooks without any digging. And by having access to our ebooks online or by storing it on your computer, you have convenient answers with campbell hausfeld pressure washer user manual . To get started finding campbell hausfeld pressure washer user manual , you are right to find our website which has a comprehensive collection of manuals listed.

Our library is the biggest of these that have literally hundreds of thousands of different products represented.



## Book Descriptions:

# **campbell hausfeld pressure washer user manual**

Read carefully before attempting to assemble, install, operate or maintain the product described. Protect yourself and Retain instructions for Each model This information If you have any Specifications questions, please call 18003300712 for customer assistance. Do not use pressure that exceeds the operating Use only authorized parts. Running the pressure washer without water will damage the pumps seals. Do not disassemble the lance or gun on this pressure washer. GROUND FAULT In the engaged position, the trigger safety latch prevents the gun CURRENT INTERRUPTER GFCI protects user from accidental from being triggered accidentally. Doing so allows the detergent to attack the deep down dirt that has worked its way into the cleaning surface. Check inlet water flow 4. Disconnect the garden hose starting and the black high pressure hose from the unit. This will relieve any pressure from the pump. Freight costs must be borne by the purchaser. C. Use reasonable care in the operation and maintenance of the pressure washer as described in the owner's manuals. Suivez toutes les instructions. Ajustez la lance selon la position du savon. Si la 18003300712 manguera explota puede causar lesiones. GFCI power cord Next Pressure Washers. Why Use a Gas Pressure Washer These gas powered pressure washers are designed for the more. Extension Poles. PW1085 6 ft. Extension Pole. PW1086 9 ft. Extension Pole. Ask question It started fine and was working and then it started to run slower and slower and then stopped. I checked the power plug and did the test on it and was fine. I let the unit cool off and tried again, still nothing. Have any ideas what happened Thank you. See replies. Pressure Washers. Product Manual Model No. Serial No. For Information About This Product, call 18003300712. Model PW4035. Contents. Page. Getting to Know Your Pressure Washer..... 3. Startup, Operation, Shutdown, and Storage..... 69. Maintenance and Technical Information..... <http://herbalnutritionshake.com/userfiles/canon-t50-manual-ebay.xml>

- **campbell hausfeld pressure washer owners manual, campbell hausfeld pressure washer manual, campbell hausfeld pressure washer 1900 manual, campbell hausfeld electric power washer manual, campbell hausfeld pressure washer pw1350 manual, campbell hausfeld pressure washer user manual, campbell hausfeld pressure washer user manual download, campbell hausfeld pressure washer user manual instructions, campbell hausfeld pressure washer user manual diagram, campbell hausfeld pressure washer user manual parts, campbell hausfeld pressure washer user manual free, campbell hausfeld pressure washer user manual user, campbell hausfeld pressure washer user manual guide, campbell hausfeld pressure washer user manual online, campbell hausfeld pressure washer user manual.**

910. Carefully read and understand these instructions REMINDER Keep your dated proof of purchase for warranty purposes! Attach it to this manual or file it for safekeeping. Operating Instructions and Parts Manual. Frequently Asked Questions. How do I start my pressure washer The engine does not come with oil. Set the fuel valve lever fully to the right in the "ON" position. What type of oil do I use Engine The engine DOES NOT COME FILLED WITH OIL. See Page 10 for engine oil types and quantities. Pump. The pump comes filled with the correct amount of oil and should not need changing or filling. Refer to Pages 9 and Why don't I have any water pressure Is the water hose attached to the pressure washer Is the water turned on Check for any kinks, leaks, or blockage in the hoses, fittings, or the nozzle. Is the quick connect tip in place See Page 5 and 6. Is the inlet filter screen free of debris. Check and remove debris if needed. How do I get high pressure Use any color tip except black. The black tip is only used for low pressure detergent application. How do I get the

soap suction to work Why doesn't the pressure washer apply detergents with high pressure  
Detergents "bounce" off cleaning surfaces as fast as they are applied. The pressure washer's  
features allow for a detergent By applying detergent at low pressure, the effect of "bouncing" is  
reduced. Also, detergents are only effective when time is allowed for them to work on the surface of  
whatever is being cleaned. After What maintenance do I need to perform on my pressure washer This  
will help protect the pump from damage. What do I do if I'm missing a part Call Campbell Hausfeld at  
18003300712 and we will promptly replace your missing parts. Do not return the pressure Where  
can I buy accessories for my pressure washer If you can't find accessories at the store where you  
purchased your pressure washer, call Campbell Hausfeld at Who do I call if I have questions or  
problems Call Campbell Hausfeld at 18003300712

U.S.A. [http://darivan.ru/cite\\_imgs/canon-t4i-user-manual.xml](http://darivan.ru/cite_imgs/canon-t4i-user-manual.xml)

Operating Instructions and Parts Manual. Safety and Warning Information. Safety Guidelines. This  
manual contains information EQUIPMENT PROBLEMS. To help Danger indicates Warning  
indicates Caution indicates a Notice indicates Risk of injection or Keep clear of nozzle. Do not  
discharge Keep clear of nozzle. NEVER direct Always wear safety glasses or NOTE Information that  
requires special Important Safety Instructions. Save These Instructions. California proposition 65.  
This product or Wash hands after handling. Never try to stop or deflect leaks Always engage the  
trigger safety Always follow detergent Do not use Explosion hazard. NEVER spray flammable  
liquids Do not remove fuel tank cap or Never disconnect the high pressure Never permanently engage  
the Never operate the machine without Equipment damage. Never put hand or fingers over  
the Occupational Safety and Health Act ALWAYS turn water supply "ON" Do not operate the pressure  
washer Keep screen clear of debris and NEVER operate pressure washer Use only the nozzle supplied  
with Never leave the wand unattended Never tamper with the engine Always hold gun and wand  
firmly NEVER allow the unit to run with NEVER store the pressure washer Freezing temperatures can  
seriously Release the trigger when changing Failure to do so could result in Keep hose away Bursting  
hoses may cause injury. Examine Do not attempt to mend a damaged hose. Unpacking. Remove the  
equipment and all parts from One pressure washer pump, engine, One cart handle assembly. One  
spray gun and quick connect Five spray tips. One high pressure hose If any parts are missing, DO  
NOT After unpacking the product, inspect it Make sure to Do not operate the Damage could result in  
bursting and Figure 3 Insert spray tips into the Figure 4. Assembly. Chemical Injector. Hose Barb.  
High Pressure. Hose See Figure 1. Pump. Outlet. Star. Knob. Thermal. Relief Pump. Inlet. Garden  
Hose. Figure 4 Pump hook up Operating Instructions and Parts Manual. Pre Operation  
Continued Trigger safety latch.

In the engaged position, the trigger Push the latch fully Always engage the trigger safety  
latch Engaged. Disengaged. Figure 8 Trigger locked. Figure 9 Trigger unlocked Never run the Figure  
7 Quick Connect Tip. Operation The following cleaning procedure will Before starting a pressure  
washer Also, protect all ALWAYS use the following start up If water has frozen DO NOT pour DO NOT  
refuel a hot Close the fuel shutoff valve during Close the choke if the engine is cold Some local  
plumbing Install a backflow NOTE The inlet water supply must have When pulling the Never let the  
starter Doing so could jam the recoil system. Pressure Adjustment. Please refer to your CAT pump  
manual Adjusting the spray fan angle. Five quick connect tips are included with The tips have  
a Pressure can also be adjusted by moving How to avoid damaging surfaces Steps 7 and 8 until the  
engine starts. Spray the cleaning surface with water to Doing so allows After the engine starts, trigger  
the gun Counterclockwise. Lower pressure. Clockwise. Higher pressure. Figure 11 Camshaft pump  
pressure Figure 14 Optimum angle to cleaning Figure 12 Narrow high impact stream. Figure 13 Wide  
fan pattern. Angle to the cleaning surface. When spraying water against a surface, The optimum  
angle for spraying water Spray water against a surface at a Damage to cleaning surfaces occurs You  
can vary the impact force by Avoid spraying The most sure way to avoid damaging Trigger the  
gun. Distance from cleaning surface. The distance between the spray tip and The impact force of the

water increases Operating Instructions and Parts Manual.

Operation Continued Note Use only detergents formulated The use of detergents can dramatically Pressure washer detergents are as thick as Once applied to a cleaning surface, You can effectively clean surfaces by Turning collar clockwise increases General Cleaning Tips NEVER replace Always engage The easiest way to regulate the cleaning Slowly move closer Note The unit also has a pressure The final rinse should start at the bottom To reduce the risk of bodily injury or NEVER turn the Serious damage could occur to the pump. NEVER disconnect Do not store the pressure washer Do not store the pressure washer Never pull the Fuel vapor from the hole can ignite by a Read the Winterizing instructions Storage Instructions above. Running the unit without spraying Hold the gun and lance in a vertical Maintenance. Observe regular maintenance intervals to Refer to the If you operate the pressure washer in Please refer to provided AR Pump. Specification page provided with your. Pressure Washer for details. Before tipping the Note Change oil while the engine is Oil Fill. Oil Drain Figure 15 Oil drain and fill locations Operating Instructions and Parts Manual. Maintenance Continued. Maintenance Schedule. Technical and Consumer Information. Maintenance Schedule. Action Needed. Horizontal Oriented Pressure Washers. Daily. Check water inlet screen and Engine Oil Type. Check engine oil levels. Fill as After first 5 hours of Every 25 hours of Check gasoline level. Fill as Change engine break in Honda Owner's Manual for Engine Oil Capacity. Honda GX390. Honda GX390. Pump Oil Type. Change oil. Replace spark plug. Each 100 hours of Replace paper air cleaner Change engine oil. AR Pumps Pump Detergent Suction. Water to detergent ratio. Clean or replace paper air Engine Fuel Capacity. Change oil if operating Every 50 hours of Manual Water Supply Requirements. Minimum inlet pressure. Maximum inlet pressure. Maximum inlet temperature. Minimum inlet flow rate. Inlet garden hose size. Maximum inlet garden hose Service Record.

Date Maintenance performed. Replacement components required Please provide following information Campbell Hausfeld. Attn Customer Service Harrison, OH 45030 U.S.A. Ref. No. Description Handle assembly. ISO mount assembly. Pneumatic wheel. Carriage bolt. Star knob. Palnut. Rubber grommet. Plug. Gun. Gun oring. Gun backup oring. Lance. High pressure hose. Pump Assembly. Engine. Socket Quick connect. Plug Quick connect Detergent Black Standard hardware item Qty. Troubleshooting Chart Gasoline Powered Pressure Washers Only. Symptom. Engine will not start or Possible Causes. Corrective Action Check fuel line and carburetor Use new fuel and dry Engine misses or lacks See service center Check inlet water flow Water leakage from Worn water seals. Install new water seals. See service center. Water in pump See service center. Frequent or premature See service center Foreign particles in the inlet or Clean or replace valves. See service center. Strong surging at the See service center. Fluctuating pressure Purge air from Pressure drops after Symptom. Possible Causes. Corrective Action Increase water pressure Pressure washer will not If detergent is dispensed Clean the barb, Notes Operating Instructions and Parts Manual. Limited Warranty OH 45030, Telephone 18003300712. Hausfeld pressure washer. C. Any failure that results from shipping damage, accident, purchaser's abuse, neglect or failure to install and operate D. Predelivery service, i.e. assembly, oil or lubricants and adjustment. E. Items or service normally required to maintain the pressure washer. F. Gasoline engine and components are expressly excluded from coverage under this limited warranty. Such components G. High Pressure Pump and components are expressly excluded from coverage under this limited warranty. AR North. America should be contacted for information on authorized repair stations for service or replacement. AR North. America may be contacted at [www.arnorthamerica.com](http://www.arnorthamerica.com) or 18008934235, extension 217. H.

Additional items not covered under the warranty B. Deliver or ship the Campbell Hausfeld pressure washer or component to nearest Campbell Hausfeld Authorized Service. Center. Freight costs, if any, must be borne by the purchaser. C. Use reasonable care in the operation and maintenance of the pressure washer as described in the owner's manuals. This Limited Warranty applies in the U.S.,

Canada and Mexico only and gives you specific legal rights. You may also have other

Manuel de Instrucciones y Lista de Piezas Modelo PW4035. Ensamblaje y Previo al Funcionamiento..... 19 20. Encendido, Funcionamiento, Apagado y Almacenamiento..... 20 23. Lea cuidadosamente y entienda estas instrucciones

Manuel de Instrucciones y Lista de Piezas. Preguntas Frecuentes Abra el pase de agua, luego presione el gatillo de la pistola para asegurarse de que el agua fluya con facilidad desde Mueva la toma de aire completamente a la izquierda. Motor El motor SE ENTREGA SIN ACEITE. Bomba La bomba se entrega con la cantidad correcta de aceite y no debe necesitar cambios o cantidades adicionales. Verifique que no haya codos o obstrucciones en las mangueras, los acoples o en la boquilla. Verifique y quite los residuos si es necesario. Use cualquier boquilla de color menos la negra. Los detergentes "resbalan" de las superficies de limpieza tan pronto como se apliquen. Llame a Campbell Hausfeld al 18003300712 U.S.A.

Manuel de Instrucciones y Lista de Piezas Peligro indica una Advertencia indica Aviso indica infor Instrucciones de seguridad Guarde estas instrucciones. Cuando use este producto, siempre se Ley de salud y seguridad ocupacional Este producto, o Use siempre gafas de seguridad y Nunca coloque la mano ni los dedos Nunca intente detener ni desviar las.

Siempre enganche el pasador de Siempre siga las recomendaciones No ejerza Peligro de No quite la tapa del tanque de Nunca desconecte la manguera de Nunca enganche el mecanismo del SIEMPRE encienda el suministro de No ponga en funcionamiento la Mantenga la rejilla libre de residuos y NUNCA opere la lavadora a No altere nunca el regulador del Siempre sostenga la pistola y la varilla. NUNCA permita que la unidad Suelte el gatillo cuando cambia de Mantenga la Examine las mangueras regularmente Retire el equipo y todas las piezas de la caja. La caja debe contener lo siguiente Si faltara cualquier pieza, NO DEVUELVA. LA UNIDAD AL COMERCIANTE. Conozca el Figura 6. No haga funcionar Utilice la perilla estrella y el perno para Figura 5 Conecte la manguera de alta Empalme para el. Manguera de. Perilla Salida Entrada de la Manuel de Instrucciones y Lista de Piezas. Pre Funcionamiento Funcionamiento Seguro del gatillo Trabado. Sin trabar No haga funcionar Funcionamiento. El siguiente procedimiento de limpieza lo Antes de empezar su trabajo de limpieza SIEMPRE use este procedimiento de Si el agua se ha Agregue aceite si es necesario. NO llene el tanque NOTA El suministro de agua en entrada Figura 10 Obturador Cuando hale del No deje nunca que Girar a la izquierda. Girar a la derecha. La distancia entra la superficie y la boquilla Distancia de la superficie a Cuando pulverice agua contra una Sin embargo, este tipo de impacto puede Pulverice agua contra una superficie a 45 Evite rociar las ventanas con un chorro Hacer esto puede Manuel de Instrucciones y Lista de Piezas Una vez aplicados a la superficie de Puede limpiar eficazmente las superficies. En superficies verticales, aplique el Consejos generales de limpieza Espere un par de minutos para que el Nunca deje secar el detergente sobre la Nunca reemplace Siempre trabe Para reducir el riesgo de lesiones personales Apague la unidad. Cierre el suministro de agua.

Suelte el seguro del gatillo y presione NUNCA cierre el sum NUNCA desconecte Para despresurizar, apague el motor, Instrucciones para la Lea las instrucciones Mantenimiento. Observe los intervalos regulares del Llenado Drenaje Figura 15 Puntos de drenaje y llenado Manuel de Instrucciones y Lista de Piezas. Programa de mantenimiento. Programa de Tipo de aceite para el motor. A diario. Verificar la rejilla y el filtro de Verificar los niveles de aceite Capacidad del aceite para el Verificar el nivel de gasolina. Cambiar el aceite de ablande Cada 25 horas de Honda GX390. Honda GX390. Cambiar el aceite. Cada 100 horas de Reemplazar el cartucho de Cambiar el aceite del motor. Tipo de aceite para la bomba. Capacidad de aceite de la AR Pumps Requisitos del suministro de Registro de servicio. Fecha Limpiar o reemplazar el Capacidad de combustible del Cada 50 horas de Repuestos requeridos Campbell Hausfeld. Attn Customer Service Harrison, OH 45030 U.S.A. Ensamble del mango. Ensamble del montaje ISO. Perno del carro. Perilla estrella. Contratuerca. Ojal de goma. Pistola. Anillo O de pistola. Anillo O de respaldo para pistola. Lanza. Ensamble de la bomba. Motor Detergente negro Nota Para mantenimiento del motor o repuestos, llame a Honda al 18004267701 Ctd. El motor no arranca o Causas posibles Llame si fuese necesario El motor pierde o

noReemplace los sellos de agua. Consulte al centro de servicioVerifique el caudal deInstale nuevos sellos de agua. Consulte al centro deConsulte al centro deFalla frecuente oConsulte al centro de servicioConsulte al centro deReemplace los sellos de aceite o los anillosO. Consulte alSellos o anilloO del aceite gastadosNotesSi se pasa detergente aManuel de Instrucciones y Lista de Piezas. Campbell Hausfeld.En algunos estados no seD. El servicio al producto antes de la venta. Ejemplo ensamblaje, aceites o lubricantes, ajustes, etc.A. Proporcionar prueba de la fecha de compra y registros de mantenimiento.IN626701AV Operating instructions.

Using the online preview, you can quickly view the contents and go to the page where you will find the solution to your problem with Campbell Hausfeld PW1310. To start viewing the user manual Campbell Hausfeld PW1310 on full screen, use the button Fullscreen. However, if you do not want to take up too much of your disk space, you can always download it in the future from ManualsBase. The option to print the manual has also been provided, and you can use it by clicking the link above Print the manual. You do not have to print the entire manual Campbell Hausfeld PW1310 but the selected pages only. paper. If you want to quickly view the content of pages found on the following pages of the manual, you can use them. With the addition of steam, you can clean, disinfect and degrease projects. The portable designs offer storage for accessories and tools. We have a wide range of products from 1300 to 1800 PSI pressure washers, and several models include steam. Refer to page 5657 for a completeExtension Pole PW1086 9 ft. Read carefully before attempting to assemble, install, operate or maintain the product described. Protect yourself and others by observing all safety information. Retain instructions for future reference. Read carefully before attempting to assemble, install, operate or maintain the product described. Protect yourself and others by observing all safety information. Retain instructions for future reference. Page 3 PW1876 Instrucciones de montaje y lista de piezas Sirvase leer y conservar estas instrucciones. Lealas cuidadosamente antes de intentar armar, instalar, operar o efectuar mantenimiento al producto descrito. Conserve estas instrucciones para futura referencia. Page 4 PW1876 Instructions de Montage et Liste de Pieces de Rechange Branchement du Systeme Suite Figure 7. PROCEDER A CETTE ETAPE CHAQUE FOIS QUE LE MODELE SOIT BRANCHE DANS UNE PRISE DE COURANT.